

# THE *NEW* WAY OF DRYCLEANING

## PRECLIN P

SEITZ PRODUCTS FOR DRYCLEANING  
- EFFECTIVE, SAFE and EASY TO USE -  
FOR BETTER PERFORMANCE

### PROCESS AND TIMES

#### 1. FIRST WASH

Low dip from work tank on pump circuit for 5 minutes charged with **PRECLIN P**, drain, pump and extract to still.

#### 2. SECOND WASH

From low level work tank complete to high level from distilled solvent tank, dose **NOVACLIN SUPER P** according to instructions in the relevant technical leaflet and filter for 6-7 minutes, drain, pump and extract back to tank.

### ADVANTAGES

1. Considerably less risk of garment damage in prespotting due to greatly reduced need for prespotting of garments.
2. Due to the excellent soil removal and soil retention properties of this system, the garments remain much brighter and with defined colours.
3. Greatly reduced re-cleans saving not only production times but also costly machine re-processing times.
4. Excellent anti-static and retexturing properties that leave the garments virtually creasefree and much easier to finish as well as being more comfortable to wear.
5. Longer filter life due to the fact that considerably more soil is removed in the first bath.
6. Less chemicals are used in the pre-wash than would normally be used at the conventional pre-brushing stage saving not only chemical cost but also distilled waste solvent.
7. Reduced risk of felting shrinkage due to the fact that much less water is being introduced into the drycleaning machine.
8. More easily handled still residue for machines with automatic still clean-out system saving machine maintenance time.
9. All advantages of an anionic detergent regarding soil removal properties combined with those of a cationic detergent in view of garment handle and anti-static.
10. Less risk of expensive claims due to misuse of chemicals and water.

The information provided herein is given on an advisory basis which does not imply and liability on our part.

PRECLIGB/4/95



**MECHMAR (PTE) LTD**  
56 Kian Teck Road  
Singapore 628791  
Tel: 6268 3048  
Fax: 6261 4049

# PRECLIN P

**Drycleaning detergent with excellent soil-removal properties for the addition to the pre-wash on totally enclosed perchloroethylene machines**

## Composition

A unique combination of high-grade anionic drycleaning substances that allow this product to be used in conjunction with SEITZ cationic detergents to obtain not only the best possible clean but also the highest standard in finish.

## Properties

**PRECLIN P** is a clear liquid drycleaning detergent for use in perchloroethylene.

**PRECLIN P** gives excellent drycleaning effect on water soluble stains and pigment soilings without the addition of water.

Numerous wet-bound stains are removed by **PRECLIN P** which greatly reduces pre-spotting and the need for post-spotting.

As **PRECLIN P** has a very low water content it makes it completely safe on all water-sensitive fabrics eliminating the risk of greying, colour loss, shrinkage and with no requirement for pre-brushing giving considerable cost savings on labour.

**PRECLIN P** is completely filterable and can be distilled without problems.

**PRECLIN P** has a neutral reaction and contains anti-corrosive additives.

## Application

**PRECLIN P** can be used in all types of dry-cleaning equipment and should be added to the first bath for optimum results.

For the very best results we recommend that **NOVACLIN SUPER P** be used on the second bath.

According to the degree of soiling of the garments to be drycleaned, add the following quantities:

## Application Process:

### 2-Bath Treatment

#### 1st Bath:

**3 to 5 ml of PRECLIN P  
per litre of solvent**

Solvent to be taken from the contaminated solvent tank - clean with **PRECLIN P** for 6 minutes at low level in pump cycle - then discharge bath to distillation

#### 2nd Bath:

**5 ml of NOVACLIN SUPER P  
per kg textiles to be drycleaned**

Solvent to be taken from the contaminated solvent tank + the clean solvent tank - clean with **NOVACLIN SUPER P** for 6 minutes - then pump second bath back to the contaminated solvent tank.

**PRECLIN P** to be added via the soap funnel or by hand into the drum prior to machine loading.



**MECHMAR (PTE) LTD**  
56 Kian Teck Road  
Singapore 628791  
Tel: 6268 3048  
Fax: 6261 4049